

Montageanvisning Storm-T



5 easy steps

1. Mark and drill a 12mm pilot hole where the saddle is to be fitted. Core the correct size hole into the host pipe. Deburr and clean the hole edges.
2. Separate the Fernco Storm-T components (rubber body, plastic collar, plastic insert with lateral seal if applicable). Fold the rubber in half and push into the hole. Pull the rubber upwards until the outer fin engages the internal surface of the pipe (see 2a). Ensure the slots on the rubber are inline with the length of the host pipe.
3. Align the tabs on the plastic collar with the external slots on the rubber body. Push the tabs on the collar into the installation slot at the top of the body. Continue to push the collar over the body,
4. Apply lubricant to the insert (profiled half only). Align the two notches on the central ring of the insert with the arrows on the collar. Push the plastic insert into the rubber body until its outer edge engages the top of the rubber.
5. Install the lateral pipe. When using a pushfit rubber sleeve, ensure that the tapered edge on the rubber sleeve does not fold back when inserted into the pipe. Lubricant may be required on the rubber.